STEVAL-ILL035V1 Schematic diagrams




Figure 2. STM32 controller




Figure 3. Connector




Figure 4. JTAG adapter (separated PCB)

